



VIBRANT CONTEMPORARY RUGS

## Hanging instructions for Sonya Winner Rugs

- Securely wall mount a piece of timber to just less than the width of the rug at a position which is calculated to be approximately 1/3 from the top of where the rug will be once hung. This timber should be cut down to around 10 cm shorter than the width of the rug before being secured to the wall so it cannot be seen when the rug is hung.
- The width and the depth of the timber should be around 4 "x 2" if the rug is heavy or if it is light you could use a thinner plank around 1" x 3"
- The timber should be securely attached to the wall with long screws at around 5cm intervals or fixed using a very strong adhesive such as "No Nails" if screws cannot be used. These items can be obtained from a builders' merchant/DIY store.
- Use long headless nails (or nails with very small heads) 5 cm at intervals to secure the rug onto the timber placed behind. The heads of these nails will be lost in the pile of the rug
- Use long panel pins or small/thin nails to secure the rug around its edges and in central parts of the rug to keep it close to the back wall.

**We display our rugs in our showroom in this way see images below:**



< Items needed for wall hanging our rugs

Please do contact us by email or phone using the details below if you need further information.

Warm wishes

*Sonya*

Sonya Winner Studio Ltd • 14 York Rise, London NW5 1ST UK • Tel: +44 (0) 20 3283 8776 • Email: [enquiry@sonyawinner.com](mailto:enquiry@sonyawinner.com)

Registered Office: 27 New Dover Rd, Canterbury CT1 3DN Registered in England and Wales. Company No. 03166803

[www.sonyawinner.com](http://www.sonyawinner.com)